

Manual, Assembly instruction: Brodit 854382

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the panelframe surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the gap openers.

2. Flip the ProClip downward so the upper angled edge hooks behind the dashboard. Press the lower part of the ProClip upward and hook the grooved edge into the lower part of the air vent.

3. Press the lower part of the ProClip downward so the grooved edge is properly in place. Pull out the gap openers.

4. The ProClip is in place.