

Manual, Assembly instruction: Brodit 854383

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame. to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard.

3. Flip the ProClip leftward so the right angled edge hooks behind the glove compartment. Hook the angled edge on the left part of the ProClip into the gap below the gap opener. Press forward on the left side of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener. Close the glove compartment.

4. The ProClip is in place.