

Manual, Assembly instruction: Brodit 854385

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the climate control panel and the center console frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the control panel and the center console frame.

2. Flip the ProClip downward/forward so the curved upper edge hooks behind the control panel.

3. Press the lower part of the ProClip upward so the lower edge goes into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.