

Manual, Assembly instruction: Brodit 854390

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Press forward on the upper part of the ProClip so the angled edge hooks into the gap next to the gap opener.

3. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.