

Manual, Assembly instruction: Brodit 854391

Angled mount ONLY for manual parking brake.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the center console side wall, to widen the gap. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the left part of the ProClip around the edge of the coin compartment.
2. Press down on the right side of the ProClip so the angled edge hooks into the gap next to the gap opener.
3. Press the angled right edge all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.