

Manual, Assembly instruction: Brodit 854394

Angled mount ONLY for models with original stereo Swing and Blues.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the center console frame and the dashboard. Press forward on the right side of the ProClip so the angled edge hooks into the gap above the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.