

Manual, Assembly instruction: Brodit 854399

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the left part of the ProClip into the gap between the stereo and the surrounding panel.
2. Press the right side of the ProClip forward so the curved left edge hooks behind the stereo.
3. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Press forward on the right side of the ProClip so the angled edge hooks into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.