

Manual, Assembly instruction: Brodit 854405

Center mount NOT for models with navigation system.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip around the dashboard edge.

2. Place your thumb on the upper part of the ProClip and press firmly forward so the angled edge hooks into the seam/gap between the dashboard and the wood grain trim. Press down on top of the ProClip to make sure the angled edge is all the way into the seam/gap, and for best possible attachment of the adhesive tape.

3. The ProClip mount is in place.

4. The ProClip mount is in place.