

Manual, Assembly instruction: Brodit 854406

Center mount, Low

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Align the upper right corner of the ProClip with the lower edge of the buttons, as shown with the white arrow on the picture. Press the angled edge on the right side of the ProClip into the gap between the floor console edge and the center console panel.

2. Place your thumb on the left side of the ProClip and press firmly down so the angled edge hooks around the sidewall edge. Press until you see or hear/feel it click into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.