

Manual, Assembly instruction: Brodit 854407

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers upwards into the seam between the console edge and the sidewall storage box, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip into the gap between the gap openers. Then pull out the gap openers.

2. Press the gap openers into the seam between the console edge and the center console sidewall. Push the ProClip towards the center console sidewall so the angled edge goes into the gap between the gap openers.

3. Press firmly down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.