

Manual, Assembly instruction: Brodit 854410

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console panel and the center console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the right side of the ProClip into the gap above to the gap opener. Pull out the gap opener.
3. Place your index fingers behind the left side of the ProClip. Pull the ProClip so it flexes towards you and hook the angled edge into the gap between the center console edge and the console sidewall.
4. The ProClip is in place.