

Manual, Assembly instruction: Brodit 854412

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip upwards, into the gap between the center console panel and the dashboard overhang.

2. Press upwards on the lower part of the ProClip and hook the angled edge into the gap between the dashboard ledge and the center console panel.

3. The ProClip mount is in place.

4. The ProClip mount is in place.