

Manual, Assembly instruction: Brodit 854417

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console edge and the padded part of the sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Hold the ProClip an almost 90 degree angled towards the sidewall and press the angled edge on the right side of the ProClip into the gap above to the gap opener. Pull out the gap opener.

3. Press the gap opener into the seam/gap in the center console edge. Flip the ProClip toward the center console, so the angled edge on the right side of the ProClip hooks behind the sidewall edge. Place your index fingers behind the ProClip face plate. Pull so the ProClip flexes towards you and hook the angled edge into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.