

Manual, Assembly instruction: Brodit 854420

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the air vent and the padded part of the dashboard.

2. Place your fingers behind the ProClip and your thumbs on the lower front part of the ProClip.

3. Push so the ProClip flexes upwards and hook the angled edge into the gap between the air vent and the padded part of the dashboard.

4. The ProClip is in place.