

## Manual, Assembly instruction: Brodit 854430

Angled mount, High

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the upper corner of the grooved edge on the ProClip into the gap below the gap opener.
3. Press forward on the lower part of the ProClip so the grooved edge goes all the way into the gap. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.