

Manual, Assembly instruction: Brodit 854432

Center mount NOT for models with storage compartment with lid.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the center console and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Hook/Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.
2. Pull out the gap opener. Pull the ProClip toward you so it flexes.
3. Hook the angled edge on the lower part of the ProClip into the upper part of the air vent.
4. The ProClip is in place.