

Manual, Assembly instruction: Brodit 854436

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.
2. Pull the ProClip upward and press the grooved upper edge into the gap next to the gap opener.
3. Press forward on the upper part of the ProClip so you hear/feel the grooved edge snaps into place in the gap. Pull out the gap opener.
4. The ProClip is in place.