

Manual, Assembly instruction: Brodit 854437

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the center console sidewall, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the climate control panel and the surrounding frame.

2. Press forward on the right side of the ProClip so the angled edge snaps into the gap above the gap opener.

3. Press on the right part of the ProClip so the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.