

Manual, Assembly instruction: Brodit 854439

Center mount ONLY for Comfort.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap, and hold it in that position. Press the left corner of the upper edge of the ProClip into the gap next to the gap opener.

2. Press down on the right part of the ProClip so the angled upper edge goes all the way into the gap. Pull out the gap opener. Pull the ProClip downward and hook the lower part into the upper part of the coin compartment.

3. Press upward on the lower part of the ProClip so the adhesive tape attaches.

4. The ProClip is in place.