

Manual, Assembly instruction: Brodit 854440

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the lower corner of the vertical grooved part of the ProClip into the gap above the gap opener.
3. Press forward on the upper part of the ProClip so all of the grooved edge goes into the gap. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.