

Manual, Assembly instruction: Brodit 854443

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener upward into the gap between the frame surrounding the air vent and the air vent housing (inside the upper part of the air vent) to widen the gap, and keep it in that position.

2. Press the right corner of the upper angled edge on the ProClip into the gap next to the gap opener. Pull out the gap opener. Press upward on the left part of the ProClip so the angled edge goes all the way into the gap.

3. Press the lower part of the ProClip upward/forward and hook the angled edge into the lower part of the air vent. Press down on the lower part of the ProClip so the adhesive tape attaches.

4. The ProClip is in place.