

Manual, Assembly instruction: Brodit 854444

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the angled edge on the left part of the ProClip onto the center console frame.
2. Press the ProClip leftward and then forward so the angled left edge hooks around the center console frame and the angled right edge hooks into the gap between the center console frame and the sidewall.
3. Press the right part of the ProClip toward the center console so the angled edge goes all the way into the gap.
4. The ProClip is in place.