

Manual, Assembly instruction: Brodit 854446

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the stereo and the panel in front of the display.
2. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap.
3. Press the ProClip forward/downward so the angled upper edge hooks around the panel in front of the display. Press until you hear/feel it snaps into place.
4. The ProClip is in place.