

Manual, Assembly instruction: Brodit 854447

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the curved edge on the right part of the ProClip into the gap between the center console frame and the sidewall
2. Press the ProClip leftward so the angled left edge hooks around the center console frame.
3. Press down on the left side of the ProClip so the adhesive tape attaches.
4. The ProClip is in place.