

Manual, Assembly instruction: Brodit 854450

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the narrow silver trim and the panel surrounding the center console, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the upper part of the ProClip into the gap between the gap openers.
3. Pull the ProClip toward you and hook the angled lower edge under the upper part of the air vent. Pull out the gap openers.
4. The ProClip is in place.