

Manual, Assembly instruction: Brodit 854451

Angled mount Does not work with models earlier than 2017 with factory navigation.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the stereo and the center console frame.

2. Press forward on the right side of the ProClip so the angled edge goes into the gap between the center console frame and the dashboard. Press the right side of the ProClip toward the center console so the angled edge goes all the way into the gap.

3. The ProClip mount is in place.

4. The ProClip mount is in place.