

Manual, Assembly instruction: Brodit 854454

Angled mount Compare the pictures with your car to match!

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the center console and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the angled edge on the left part of the ProClip into the gap between the stereo and the center console frame.
3. Press forward on the right side of the ProClip so the angled edge snaps into place in the gap above the gap opener. Press the right part of the ProClip toward the center console so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.