

Manual, Assembly instruction: Brodit 854457

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be placed anywhere within the width of the stereo.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip under the trim, between the stereo and the frame surrounding the air vent.
2. Press the lower part of the ProClip upward, in the same time press the upper part forward.
3. Press the upper part of the ProClip forward so the angled edge hooks over the panel.
4. The ProClip is in place.