

Manual, Assembly instruction: Brodit 854460

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the upper corner of the grooved edge on the ProClip into the gap between the control panel and the dashboard.

2. Press forward so all of the grooved edge goes all the way into the gap. Press until you hear/feel it snaps into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.