

Manual, Assembly instruction: Brodit 854462

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. Fits models with and without factory navigation screen.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener. Flip the ProClip downward so the curved upper edge hooks underneath the dashboard.

3. Pull the ProClip toward you and hook the angled lower edge into the gap between the center console overhang and the stereo. Press the ProClip forward so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.