

Manual, Assembly instruction: Brodit 854463

Center mount The 2015 dash is not same in all countries, visually confirm your dash.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the coin compartment, to widen the gap. Press the right corner of the ProClip into the gap next to the gap opener.

2. Press the ProClip downward so the angled edge goes all the way into the gap. Pull out the gap opener.

3. Press the gap opener into the gap between the coin compartment and the dashboard. Press the upper part of the ProClip forward/downward so the angled edge hooks into the gap next to the gap opener. Pull out the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.