

Manual, Assembly instruction: Brodit 854467

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin angled edge on the enclosed gap opener into the gap between the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Pull the ProClip toward you and hook the angled edge on the lower part under the dashboard overhang.

4. The ProClip is in place.