

Manual, Assembly instruction: Brodit 854470

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the coin compartment and the dashboard.
2. Flip the ProClip downward so the upper curved edge hooks under the coin compartment.
3. Press the ProClip downward so the angled lower edge hooks under the dashboard overhang.
4. The ProClip is in place.