

Manual, Assembly instruction: Brodit 854473

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the instrument panel and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the angled edge on the left side of the ProClip firmly into the gap between the gap openers. Pull out the gap openers.
3. Press the gap openers into the gap between the center console and the dashboard. Press the ProClip firmly to the right and forward so the angled right edge goes into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place.