

Manual, Assembly instruction: Brodit 854480

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the trim and the control panel. Flip the ProClip downward/forward so the curved upper edge hooks behind the control panel.
2. Press the lower part of the ProClip forward so the angled lower edge hooks under the trim.
3. Press the lower part of the ProClip upward so the adhesive tape attaches.
4. The ProClip is in place.