

## Manual, Assembly instruction: Brodit 854493

Center mount



**Please read all of the instructions and look at the picture before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the thin angled edge on the lower part of the ProClip into the seam/gap between the air vent and the surrounding panel frame.
2. Press firmly down on top of the ProClip so it flexes downward. Then hook it into the seam/gap between the air vent and the surrounding panel frame. Release the pressure on top of the ProClip.
3. Place your finger underneath the ProClip and press upwards to make sure the angled edge is all the way into the gap.
4. The ProClip is in place.