

Manual, Assembly instruction: Brodit 854495

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the thin angled edge on the upper part of the ProClip into the seam/gap between the air vent and the surrounding panel frame. Note: You may have to wiggle the ProClip a little to get the edge to go into the gap.

2. Press firmly forward on the lower part of the ProClip so angled edge hooks it into the seam/gap between the air vent and the surrounding panel frame. Press until you see or hear/feel it clicks into place.

3. The ProClip mount is in place.

4. The ProClip mount is in place.