

Manual, Assembly instruction: Brodit 854497

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the air vent and the padded dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Hook the angled edge on the lower part of the ProClip around the frame surrounding the air vent.
3. Push firmly forward on upper part of the ProClip so the ProClip flexes forward and reaches the gap. Press down on the top left corner of the ProClip so the angled edge goes into the gap next to the gap opener. Then press down on the right corner. Pull out the gap opener.
4. The ProClip is in place.