


Manual, Assembly instruction: Brodit 854498

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console edge and the center console panel frame, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip.

2. Press the thin curved edge on the right side of the ProClip into the gap above the gap opener. Then flip it to the left so the curved edge hooks behind the center console panel.

3. Place your index fingers behind the left side of the ProClip and pull towards you, and then hook the angled edge into the gap in the sidewall. Pull out the gap opener.

4. The ProClip is in place.