

Manual, Assembly instruction: Brodit 854503

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the console sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the thin curved edge on the right side of the ProClip into the gap below the gap opener.

2. Place the fingers on your right hand towards the end of the ProClip to hold the curved edge in place in the gap while flipping the ProClip, with your left hand, towards the center console.

3. Place your index fingers behind the ProClip. Pull towards you, and then hook the angled edge on the left side of the ProClip over the console edge. Pull out the gap opener.

4. The ProClip is in place.