

## Manual, Assembly instruction: Brodit 854514

Angled mount



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the grooved edge on the left part of the ProClip into the gap below the gap opener.

**2.** Press forward on the upper part of the ProClip so the grooved edge snaps into the gap.

**3.** Press forward on the lower part of the ProClip so the grooved edge snaps into the gap. Press alternately on the upper/lower part of the ProClip until you hear/feel that all the grooved edge snaps into place. Pull out the gap opener.

**4.** The ProClip is in place.