

Manual, Assembly instruction: Brodit 854516

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the upper part of the ProClip into the gap between the gap openers. Pull out the gap openers. Press the upper edge on the ProClip all the way into the gap.

3. Press a gap opener into the gap between the air vent and the center console. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener. Place your index fingers inside the ProClip and press downward on the lower part so the angled edge goes all the way into the gap and the adhesive tape attaches.

4. The ProClip is in place.