

Manual, Assembly instruction: Brodit 854517

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on Part 1. Place Part 1 straight over the air vent. Press the curved edge on part 1 into the gap under the dashboard overhang. Slide Part 1 leftward in the gap, until it stops. Flip Part 1 upward so the curved edge hooks into the gap and the adhesive tape attaches.

2. Peel off the adhesive tape cover on Part 2. Press the angled edge on the lower part into the gap between the air vent frame and the dashboard. Press Part 2 forward and then firmly downward, so the angled edge hooks behind the air vent frame.

3. Place Part 2 onto Part 1 so the holes match. Attach Part 2 onto Part 1 by using the enclosed screws.

4. The ProClip is in place.