

Manual, Assembly instruction: Brodit 854523

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the panel surrounding the air vent and the control panel.
2. Hook the angled edge on the upper part of the ProClip over the frame surrounding the control panel.
3. Press downward on the top of the ProClip so the angled edge hooks properly into place and the adhesive tape attaches.
4. The ProClip is in place.