

## Manual, Assembly instruction: Brodit 854528

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the enclosed gap opener into the gap between the center console and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.

2. Pull the ProClip toward you and hook the angled lower edge under the upper edge of the air vent. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.