

Manual, Assembly instruction: Brodit 854535

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place. This mount consists of two parts.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin end of the enclosed gap openers into the gap between the padded center panel frame and the dashboard surrounding the instrument panel, to widen the gap. Press the angled edge on the attaching part of the mount (the smaller part) into the gap between the gap openers. Press it forward into the gap and flip it rightwards so the adhesive tape attaches. Pull out the gap openers and press them into the gap between the center panel and the surrounding padded frame.

2. Press the left edge of the mount part with the face plate into the gap between the gap openers. Align the holes in the part with the face plate over the holes in the attaching part. Pull out the gap openers.

3. Screw the parts together with the enclosed screws.

4. The ProClip mount is in place.