

Manual, Assembly instruction: Brodit 854536

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the glove compartment frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Hold the ProClip in an almost 45 degree angle and press/hook the angled right edge into the gap above the gap opener. Flip/push the ProClip to the left so the angled edge on the right side of the ProClip hooks behind the glove compartment frame.

3. Place your fingers behind the left side of the ProClip and pull so it flexes towards you. Then hook it over the console edge and press/slide the curved edge into the gap between the center console panel and the padded console edge. Pull out the gap opener and close the glove compartment door.

4. The ProClip is in place.