

Manual, Assembly instruction: Brodit 854537

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the left side of the ProClip around the console edge in the sidewall.

2. Place your fingers underneath the right side of the ProClip. Pull upwards and hook the angled edge on the right side of the ProClip over the console edge, and into the gap between the console edge and the center console panel.

3. Press firmly down on the top right side of the ProClip to make sure the angled edge is all the way into the gap, and for best possible attachment of the adhesive tape.

4. The ProClip is in place.