

Manual, Assembly instruction: Brodit 854540

Center mount NOT for wood grain panel.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the ignition key and the instrument panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the thin edge on the upper part of the ProClip into the gap between the instrument panel frame and the padded dashboard overhang.
3. Place your finger on the lower part of the ProClip. Push firmly upwards and hook the curved edge into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is now in place