

Manual, Assembly instruction: Brodit 854543

Angled mount NOT for models with high built in navigation system.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the upper part of the ProClip around the air vent edge.

2. With your one hand, press down on top of the ProClip behind the face plate and with your other hand, pull the lower part of the face plate so it flexes towards you. Hook the lower angled edge around the dashboard edge.

3. The ProClip mount is in place.

4. The ProClip mount is in place.